



THE

*Indian*

MOTORCYCLE COMPANY • 1535 West Rosecrans Avenue, Gardena, Calif. 90249

SVB-125

# ME-76

## SET UP INSTRUCTIONS FOR ME-76

1. Receiving Instructions
  - A. Carefully remove all packaged parts from the box.
  - B. Remove front wheel from the box.
  - C. Remove all the protective wrapping.
  - D. Carefully lift the motorcycle out of the box.
2. Assembly Instructions
  - A. Assemble the handlebars onto the top crown.
    - (1) The speedometer assembly should be placed on top of the handlebar clamps.
  - B. Assemble the front wheel onto the forks.
  - C. Bolt the rear shocks into the top shock mounts.
  - D. Assemble the control cables and light switch to the handlebar.
  - E. Bolt the taillight to the rear fender and plug in color coded wires.
  - F. Bolt on rear turn signals and plug into color coded wires. (if included)
  - G. Remove the two headlight holding bolts and replace with the front blinker assemblies. Connect the color coded wires from the blinkers to the headlight wiring harness. (if included)
  - H. Assemble the footpegs to the frame. Remove the air cleaner and soak with 30 wt. oil and squeeze out excess oil and replace the foam element onto the carburetor.

