

# SERVICE BULLETIN



THE  
*Indian*  
MOTORCYCLE COMPANY

**Bulletin No.** SVB-152

**Model** MM-5A and JC-5A

**Subject** SET-UP

**Date** March 14, 1974

## SET UP INSTRUCTIONS MM-5A AND JC-5A

### 1. RECEIVING INSTRUCTIONS:

- (A) Carefully remove all packaged parts from the box.
- (B) Remove front wheel from the box.
- (C) Carefully lift the motorcycle out of the box.
- (D) Remove all the protective wrapping.

### 2. ASSEMBLY INSTRUCTIONS:

- (A) Remove the two 10 mm bolts, washers, and large steering crown nut from the fork tube assembly.
- (B) Align handlebars/fork crown properly on fork tube. Replace the bolts and nuts and tighten.
- (C) Flip the motorcycle upside down and install the front wheel assembly, and tighten up the axle nuts.
- (D) Install the foot peg assembly to the bottom mount and tighten up the two bolts.
- (E) Turn the motorcycle over and install front brake cable into the clamp and tighten. Adjust the front brake for 1/2 inch free play at lever tip.
- (F) Adjust rear brake cable so that the lever has 1/2 inch free play at lever tip.
- (G) Check for tightness of ALL nuts and bolts.

### 3. INITIAL LUBRICATION PROCEDURE:

- (A) Remove drain plug and drain shipping oil. Reinstall drain plug and tighten.
- (B) Lay motorcycle on the left side and fill transmission through oil plug on clutch cover:
  - (i) Fill transmission with 10 ounces of 30 weight non-detergent oil.

